




Daily Maintenance Guide

- Open the door
- Remove the waste bin and drip tray. Empty them and put them back into the machine.

Refilling:

Lift up the lid of the machine. Remove the lid of the desired individual canister. Fill up the canister with the applicable product (coffee, milk powder (1), or hot chocolate powder(2)) and put the lid(s) back.




NOTE: Do not have the milk or chocolate canisters open when filling the coffee. If a coffee bean falls into one of the soluble canisters it will end up plugging the dispenser hose and cause the machine to leak.

Rinsing:

Place a mug under the spout. Touch the menu tab on the lower left corner of the display screen. Select "rinse machine" and follow the prompts.



*Caution: the coffee brewer will rotate multiple times and hot water will dispense multiple times. Keep hands out of the machine while the rinse cycle is happening.



Note: the machine is programmed to request a rinse daily at 8 AM (or every 50 cups) The time can be changed if desired.



Full instructional Video

Further questions call Mill creek coffee: 604-552-2739